

<u>1934:</u>	<u>1939:</u>	112.051 - 113.270	3.005.001 - 3.007.191
105.001 - 105.400	106.550 - 106.760	112.090 - 113.270	<u>1951:</u>
110.001 - 110.010	110.970 - 111.700	<u>1947:</u> (PVS)	5.105.001 - 5.105.404
117.501 - 117.540	118.175 - 118.180	113.271 - 117.210	3.105.001 - 3.108.103
<u>1935:</u>	125.370 - 125.500	118.480 - 118.800	2.105.001 - 2.107.878
105.401 - 105.585	125.540 - 125.660	<u>1948:</u>	<u>1952:</u>
110.005 - 110.010	<u>1940:</u>	5.480.001 - 5.480.306	2.205.001 - 2.206.948
117.451 - 117.625	106.760 - 106.805	2.480.001 - 2.482.612	3.205.001 - 3.207.787
125.001 - 125.050	111.700 - 111.800	2.485.001 - 2.485.677	5.205.001 - 5.205.169
<u>1936:</u>	118.180 - 118.280	3.480.001 - 3.480.828	<u>1953:</u>
105.535 - 105.880	125.500 - 125.525	3.485.000 - 3.485.124	2.305.001 - 2.306.300
110.010 - 110.035	125.660 - 125.690	<u>1949:</u>	3.305.001 - 3.306.333
117.625 - 117.690	<u>1941:</u>	5.490.000 - 5.490.041	5.305.001 - 5.305.143
125.050 - 125.150	111.800 - 111.940	5.495.001 - 5.495.315	<u>1954:</u>
<u>1937:</u>	118.280 - 118.415	2.490.001 - 2.492.050	3.405.706 - 3.405.850
105.880 - 106.300	<u>1942:</u>	2.495.001 - 2.497.134	3.405.854 - 3.405.891
117.690 - 117.820	111.940 - 112.000	3.490.001 - 3.490.900	2.405.001 - 2.405.911
125.150 - 125.280	118.415 - 118.450	3.495.001 - 3.495.925	6.405.001 - 6.405.020
<u>1938:</u>	<u>1943:</u>	<u>1950:</u>	<u>1955:</u>
106.300 - 106.550	112.000 - 112.050	5.000.001 - 5.000.007	2.505.001 - 2.505.313
110.347 - 110.970	118.450 - 118.480	5.005.001 - 5.005.555	3.505.001 - 3.505.287
117.820 - 118.175	<u>1945:</u>	2.000.001 - 2.000.568	<u>1956:</u>
125.280 - 125.370	112.050 - 112.090	2.005.001 - 2.007.429	2.605.001 - 2.605.160
125.501 - 125.540	<u>1946:</u> (PVS)	3.000.001 - 3.000.224	3.605.001 - 3.605.081

Chassiscode na 1948 : 2=11BL 5 =15-6
3=11B 6 =15-H